169

N64-26353 Code-1 Cat. 25 nasa Ov-56724

XEROX \$ //d/ p.



HYDRONAUTICS, incorporated research in hydrodynamics

Research, consulting, and advanced engineering in the fields of NAYAL and INDUSTRIAL HYDRODYNAMICS. Offices and Laboratory in the Washington, D. C., area: Pindell School Road, Howard County, Laurel, Md.

CUARTERLY REPORT

CAVITATION DAMAGE IN LIQUID METALS

Report of Progress for the Period

2 April 1963 - 2 July 1963

Ву

H. S. PREISER A. THIRUVEN ADAM

1 September 1963

Prepared for National Aeronautics and Space Administration Contract No. NASr 105

Technical Management
NASA Lewis Research Center
Space P wer Systems Division
James P. Couch

HYDRONAUTICS, Incorporated Pindell School Road Laural, Maryland

NOTICE

This report was prepared as an account of Government sponsored work. Neither the United States, nor the National Aeronautics and Space Administration (NASA), nor any person acting on behalf of NASA:

- A.) Makes any warranty or representation, expressed or implied, with respect to the accuracy, completeness, or usefulness of the information contained in this report, or that the use of any information, apparatus, method, or process disclosed in this report may not infringe privately owned rights; or
- B.) Assumes any liabilities with respect to the use of, or for damages resulting from the use of any information, apparatus, method or process disclosed in this report.

As used above, "person acting on behalf of NASA" includes any employee or contractor of NASA, or employee of such contractor, to the extent that such employee or contractor of NASA, or employee of such contractor prepares, disseminates, or provides access to, any information pursuant to his employment or contract with NASA, or his employment with such contractor.

Reduests for copies of this report should be referred to:

National Aeronautics and Space Administration Office of Scientific and Technical Information Washington, D.C., 20546 • Attention: AFSS-A

CAVITATION DAMAGE IN LIQUID METALS

Report of Progress for the Period

2 April 1963 - 2 July 1963

SUMMARY:

During the current period maximum effort was applied to design a new research test facility for cavitation damage testing of refractory materials in liquid sodium at high temperature. A feasibility study has been completed which will incorporate a sodium loop into a vacuum dry box. The new dry box will include an integral elevating mechanism to house the magnetostriction device and allow in place calibration. Detailed purchase specifications are in preparation and invitations to bid will be circulated to qualified manufacturers in the early part of the next report period.

A systematic series of experiments were performed to determine how small variations of geometric parameters associated with the magnetostriction apparatus would affect cavitation damage rate with a view toward standardizing test conditions for all future experiments. The results indicate that beaker size, liquid depth and depth of immersion have no effect on cavitation damage rate within the limits tested. Specimen size appears to affect the damage rate considerably and therefore a fixed size is necessary. This size is based primarily on convenience of specimen preparation and ease of examination.

It has been established that a rimmed specimen is not required to achieve reproducibility of damage in the steady zone. A flat faced specimen is more desirable since it has equal reproducibility to the rimmed type, is not subject to

localized rim damage, and is more convenient and less expensive to machine and make visual observations.

A work schedule for the next period is included at the end of the report.

EXPERIMENTS TO STANDARDIZE THE TEST PARAMETERS OF MAGNETO-STRICTION APPARATUS:

The essential test parameters of the magnetostriction apparatus are shown in Figure 1. The nomenclature is as follows:

- a amplitude of vibration of the specimen
- r frequency of oscillation
- r radius of the specimen
- d depth of immersion of the specimen
- H depth of test liquid in the heaker
- D diameter of the beaker
- λ wave length of sound in the liquid

So far there has never been any systematic analysis of the effect of the above parameters on the rate of cavitation damage except a few isolated experiments without any specific conclusions. Before undertaking any detailed investigations on the resistance of materials by making use of this apparatus, it is necessary to know the effect of small variations in the above parameters so that proper care will be taken to control them as required. With this objective in view the following experiments were carried out under the present program of research. Tap water and aluminum specimens were used in these experiments as a matter of speed and convenience.

Effect of Specimen Shaper It is the general practice to use a circular test specimen with a flat test face (shown in Figure 2(b) for Cavitation damage tests. However, Pleaset (1) reported that it was difficult to get reproducible results with

this ::) st faced specimen and introduced the "dished" specimen idea (as shown in Figure 2(a) with the claim that this type of specimen would give a better reproducibility of the results. During the present experiments with liquid sodium it was found that the rim damage (the rlm of the specimen would break off In the middle of an experiment due to the damage produced by a ring of bubbles entrapped in the tip vortices) was a serious difficulty with this type of experiment. Furthermore, the machining and control of the test surface finish are much more difficult than the flat faced specimens. These considerations lead to a reexamination of the effect of specimen shape with particular reference to the necessity of the rim. Figure 3 shows the relationship between the damage rate and the testing time for four identical flat faced specimens at a given amplitude and frequency. Figure 4 shows the same relationship for three identical Plesset, dished specimens. The amplitude in this case had to be lower because of rim damage at higher amplitudes. One can easily see that the reproducibility of results with a flat faced specimen is in no way inferior to the specimens with rim. Figure 5 shows the rate of damage as a function of amplitude for both types in the steady zone and there seems to be no difference provided there is no rim damage. It has been decided to adopt a simple flat faced specimen as a result of these investigations.

Effect of Depth of Test Liquid in The Beaker: It has been suggested earlier that the depth of liquid in the beaker had an effect on the damage rate because of the wave reflections in the liquid (2). It has been further recommended that this depth should be a half wave length of sound in that liquid for the test frequency so that a standing wave is produced. Figure

5 shows the relationship between the rate of damage and the relative depth of liquid (water) with respect to the wave length at 15 kc/s. There seems to be little effect on damage rate due to the wave reflections up to about 2 1/2 wave lengths. It has been observed that the damage rate decreases if the depth is decreased below 0.3 wave length. Hence the depth of liquid in the beaker will be kept more than a half wave length.

Effect of the Diameter of the Beaker: There seems to be little effect of the diameter of the beaker on the rate of damage as shown in Figure 7. (Showing the relationship between the rate of damage and the relative diameter with respect to the wave length of sound in the test liquid).

Effect of Depth of Immersion of Specimen: Rheingans (3) found that the depth of immersion of the test specimen had an effect on the cumulative damage; furthermore, this effect depended upon the test duration. Because of the two interacting variables, he failed to come to a definite conclusion regarding the magnitude of the effect of the depth of immersion on damage. Present experiments on this aspect conducted in the steady zone (thereby eliminating the time effects) show that the rate of damage in the steady zone is independent of the depth of immersion of the test specimen up to one radius of the specimen as shown in Figure 8.

Standardization of Test Parameters: As a result of this analysis, the following criteria for standardization of the test parameters in the magnetostriction apparatus have been formulated. The beaker dimensions do not seem to have any specific effect on the rate of damage and hence a reasonably practical size may be selected. The rate of damage is independent of the depth of immersion of the specimen up to one radius of the specimen. A flat faced specimen may be selected for testing

because of its simplicity. Experiments on the effect of variation of specimen diameter on damage rate is in progress and will be reported during the next period.

PLANS FOR THE NEXT REPORT FERIOD

- 1. Purchase new refractory dry box and all associated components and instrumentation.
- 2. Perform accelerated cavitation damage tests of pure iron, nickel 201 and titanium 100A in liquid sodium up to 1000°F. and compare with available water data.
- 3. Determine effect of amplitude and temperature on the cavitation damage rate of 2.
- 4. Perform experiments to correlate the change in damage rate as a function of specimen diameter.

REFERENCES

- 1. Plesset, M.S., On Cathodic Protection in Cavitation Damage, Trans. A.S.M.E., Journal Basic Engineering, Dec. 1960, p. 809.
- 2. Robinson, L.E., B.A. Holmes and W. C. Leith, Progress Report on Standardization of The Vibratory-Cavitation Test, Trans. A.S.M.E., Vol. 80, 1958, pp. 103-107.
- 3. Rheingans, W.J., Accelerated-Cavitation Research, Trans. A.S.M.E., Vol. 72, 1950, p. 709.






FIGURE 1. DEFINITION SYETCH OF THE MEGNETOSTRICTION APPARATUS

HYDRONAUTICS, Incorporated





a) Plesset's Rimmed Specimen



b) Flat Specimen

FIGURE 2. TWO TYPES OF SPECIMENS TESTED FOR REPRODUCIBILITY





annutuu/eRuu - eeon quetam 10 820)

HYDAONAUTICS, Incorporated

· (5°)

Flat Faced Specimen

Plesset's Rimmed Specimen

Frequency

15 kc/s

Material: 1100-0-Aluminum Liquid: Water © 80°F.






FIGURE 5. RATE OF WEIGHT LOSS VS AMPLITUDE FOR BOTH TYPE OF SPECIMENS






Rate of Weight Loss


- mgs/min.

EFFECT OF DEPTH OF LIQUID IN THE BEAKER FIGURE 6.

3,

3





Rate of Weight Loss

FIGURE 8.

EFFECT OF DEPTH OF IMMERSION OF MATER